

SANITARY DEEP CLEANERS

PREMIUM QUALITY
MADE IN GERMANY



SANEX®

DEEP CLEANER AND CEMENT RESIDUE REMOVER

PROPERTIES

Powerful cleaner for post-construction cleaning, cement residue removal and for removing residues from stainless steel surfaces. SANEX is also a high-performance deep cleaner for removing limescale deposits, rust stains, urine and other residues on acid-proof surfaces in swimming pool, sanitary and kitchen areas.

- Acidic deep cleaner with phosphoric acid-based formula
- Integrated corrosion inhibitor
- Does not damage materials; free of hydrochloric acid

APPLICATION AREAS

Can be used for deep cleaning as well as for daily cleaning, for example in bathrooms with higher water hardness. NOT for use on acid-sensitive surfaces such as toilet seat covers, marble, lime-containing stone, granite, chrome, enamel, zinc, nickel, aluminum, or similar; or on enamel, nickel and zinc that fall under **DIN ISO 2722**.

APPLICATION

Liberal pre-wet surfaces!

Deep cleaning: Apply to surfaces undiluted or diluted 1000 ml to 10 liters of water. Depending on the degree of soiling, allow the cleaning liquid to work on the surface for a few minutes. For extremely heavy soiling, repeat the process.

Routine cleaning: Dilute 100–200 ml to 10 liters of water. After cleaning, thoroughly rinse the treated areas with copious amounts of clean water. This removes any product residue and prevents surface damage caused by residual acid.

INGREDIENTS

<5% nonionic surfactants. Contains perfumes, ALPHA-ISOMETHYL IONONE.



pH-value in concentrate

1

0 2 4 6 8 10 12 14

Containers

ART.-NO.

1 L

01020

10 L

01003

UN 1805



Warning

Contains phosphoric acid
Causes severe skin burns and eye damage.

- Before always read the indications and product information.
- For commercial / industrial use only!
- Reusable containers

- Keep out of reach of children.
- Wear protective gloves/eye protection.
- IF SWALLOWED: rinse mouth. Do NOT induce vomiting.
- IF ON SKIN (or hair): Remove immediately all contaminated clothing. Rinse skin with water.
- IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
- Immediately call a POISON CENTER or doctor.



ARCORA® INTERNATIONAL

Marsstraße 9 • 85609 Aschheim near Munich - Germany
Fon: +49 (0)89 - 14 33 29 30 • Fax: +49 (0)89 - 14 33 29 329

www.arcora-group.com
info@arcora.de